

How to build a basic ZipWall dust barrier

Roll out plastic sheeting for length of barrier

Attach plastic sheeting to the first pole and raise the barrier one pole at a time. Work from one end of the barrier to the other. As you raise each pole to the ceiling, pull the sheeting tight between the tops to eliminate sags. Do not tuck plastic under the pole feet at this time.

Place poles 8' - 10' apart; If negative air is used or if there is a lot of air flow, place poles closer, about 6' apart.

Compress the spring loaded top of each pole about half way. This will let you raise the pole to reposition the barrier if needed.

After all the poles are up, start at one end of the barrier and tuck the sheeting under the pole feet, one pole at a time.

Finally, raise each pole to fully compress the spring loaded mechanism for maximum tension on the barrier. Work from one end to the other.

